

Course Content of SL500 Operations Overview

Component Locations

- Base module
- Robotics unit
- Keypad
- Slot numbering scheme (library, module, row, column)
- Power switch
- Power cords/strip
- Tape drives
- Cooling fans

Controls and Indicators

- Keypad
- Local operator panel

Cartridge Information

- Handle the cartridges
- Identify the cartridge components
- Apply labels
- Set the write-protect switch

Library Operation

- Open the front door
- Enter a cartridge and eject a cartridge through the CAP
- Power on and off the library
- Open the front door and lock the front door (without power)
- Locate and remove a cartridge
- Insert and remove a cartridge from a tape drive

- Return the library to ready status

Access SLC (password)

- Use the Details screen to describe what components are in the library
- Use the Reports screen and understand and print the reports

Troubleshooting

- Use the troubleshooting table
- Use LEDs
- Use SLC
- Know how to contact CSSC

Partitioning feature

- How to configure the partitions and operate the CAP when partitioning is present.